

取扱説明書

⚠ 製品について

素材の特性上、一つ一つ手作業で仕上げているため、本体に多少のスリ跡などが付くことがあります。ご了承ください。

手斧

薪に斧を食い込ませ、薪ごと「コンコン」と硬い地面に叩き付けて割っていきます。ある程度食い込んでしまったものはそのままコンコン叩けば割ることができます。少ない力と重さで叩いていくと安全に割ることができます。

⚠ ご使用上のご注意

●木割り用です。目的以外には使用しないでください。●必要以上の高さから振り下ろしたり、無理な力を加えると、斧がねじれて薪からはずれ大変危険です。●斧を腕で振ろうとすると、疲れるだけでなく怪我の危険も増えます。斧の重みで割るようにしてください。●濡れた状態で放置するとすぐに痛みます。刃が錆びないよう、乾いた室内で保管してください。●お子様の手の届かない所に保管してください。●落下させたりすると破損の原因になります。●刃先を素手で直接触らないでください。●斧を大きく振り下ろさないでください。●火器に近づけないでください。●記載以外の用途には使用しないでください。●本製品に刃こぼれやガタツキ、ひび割れがないかを確認してください。●手を保護するため手袋(軍手、革手)を着用してから作業を行ってください。

使用方法

1.刃先を薪に軽く食い込ませてください。(食い込みが悪い場合には斧の背中部の中心から先端にかけて叩いてください。)2.軽く食い込んだら、利き手で斧を持ち、空いている手で薪を掴んで一緒に土台に打ち付けてください。3.両刃仕様のため左右どちらの利き手もご使用いただけます。※刃先が薪に食い込んだ状態でねじったりしないでください。(刃先が欠ける恐れがあります。)

お手入れ・保管について

●ご使用後は乾いた布などで、汚れや水分をふき取ってください。●頑固な汚れには薄めた中性洗剤に浸した布を固く絞ってふき取ってください。その後は市販の刃物油やさび止め油を塗って革ケースで保管してください。●切れ味が悪くなったり、刃が欠けたりしたら、砥石を軽く水で濡らし、荒い砥石で研いだ後、細かい砥石で仕上げます。



About the product

Due to the properties of the material each part is finished individually by hand. For this reason, some fine scratches may be left on the axe. We would ask for your understanding.

Axe

Firewood will split if you wedge the axe in each piece of wood and strike it firmly several times on the hard ground. Pieces of wood in which the axe is already suitably wedged can be split just by striking on the ground. Wood can be safely split without using much force.

⚠ Precautions for use

- For splitting wood. Do not use it for any other purpose. - If you bring the axe down from too high a point or apply excessive force, the axe will twist and slip out of the wood. This is very dangerous. - Swinging the axe with your arm is not only tiring but also increases the risk of injury. Use the weight of the axe to split firewood. - Leaving the axe lying around when it is wet will immediately damage it. Store the axe somewhere dry indoors to prevent the blade from getting rusty. -Store out of the reach of children. - Dropping the axe may damage it. - Don't touch the tip of the blade with your bare hands. - Don't bring the axe swinging down too heavily. - Don't let the axe get too close to the fire. - Do not use it for any purpose other than those specified. - Check that there are no chips in the blade and that it is not shaky or cracked. - To protect your hands, wear gloves (work or leather) before using the axe.

How to use

1. Lightly wedge the tip of the axe into the firewood. (If the "bite" is poor, strike from the center of the back of the axe towards the tip.) 2. Once the axe is lightly wedged, hold it with your dominant hand and gripping the firewood with your free hand strike axe and wood together on the base. 3. Since the axe is double-edged you can use whichever hand is stronger. * Do not twist the edge of the blade while it is wedged in the firewood. (There is a risk that the blade might break.)

Care and storage

- After use, wipe off dirt and moisture with a dry cloth. - Remove stubborn dirt by wiping with a cloth that has been soaked in diluted neutral detergent and carefully wrung out. Then coat with commercial knife oil or anti-rust oil and store in leather case. - If the edge becomes blunt or gets chipped, lightly wet a grindstone and after polishing with the rough grindstone, finish with a fine stone.

〈品質表示 Quality Indication〉

材質: 本体: 刃物鋼(鉄) カバー: 革
幅: 約100mm(刃部分) 縦: 約298mm
厚さ: 約6mm 重量: 約619g

Main Body: Carbon steel cover: leather
Width: approx.100mm Height: approx.298mm
Depth: approx.6mm Weight: approx.619g