

取扱説明書

⚠ 製品について

素材の特性上、一つ一つ手作業で仕上げているため、本体に多少のスリ跡などが付くことがあります。ご了承ください。



注意

ケガや器具損傷の原因となります。

- 刃先を素手で直接触らないでください。
- 振り回さないでください。
- 火気に近づけないでください。
- 子供の遊び道具にしないでください。
- 金属類の切断には使用しないでください。



- 竹等の縦繊維の強い物に、横から鉋を振り下ろしても、はね返る恐れがあります。ケガや器具損傷の原因になりますのでおやめください。竹等の縦繊維の強い物はノコギリでの切断をおすすめします。

⚠ ご使用上のご注意

- 必要以上の高さから振り下ろしたり、無理な力を加えると、ナタがねじれて薪からはずれ大変危険です。●ナタを腕で振ろうとすると、疲れるだけでなく怪我の危険も増えます。ナタの重みで割るようにしてください。●濡れた状態で放置するとすぐに痛みます。刃が錆びないように、乾いた室内で保管してください。●お子様の手の届かない所に保管してください。●落下させたりすると破損の原因になります。●刃先を素手で直接触らないでください。●ナタを大きく振り下ろさないでください。●火器に近づけないでください。●記載以外の用途には使用しないでください。●本製品に刃こぼれやガタツキ、ひび割れがないかを確認してください。●手を保護するため手袋(軍手、革手)を着用してから作業を行ってください。●第三者に譲渡・貸与される場合も、この説明書を必ず添付してください。

使用方法

- 【割る場合】薪割り等は対象物の下に木台を置いてください。(誤って地面に刃先をぶつけ、器具損傷及びケガを防ぐ為)木が割れない場合、補助具(木槌等木製の物)でナタの背を叩いて割ります。
- 【切る場合】(枝打ち等)樹木の枝打ちは、切り落としたい枝が幹の左右に出ている、刃の形状上、刃を幹に食い込ませることなく枝打ちが出来ます。
- 【削る場合】樹木の伐採及び幹を細く削る場合等は、幹の繊維に対し斜めに刃先を打ち込むと刃のさざりが良いです。※刃先が薪に食い込んだ状態でねじったりしないでください。(刃先が欠ける恐れがあります。)

お手入れ・保管について

- ご使用後は乾いた布などで、汚れや水分をふき取ってください。●頑固な汚れには薄めた中性洗剤に浸した布を固く絞ってふき取ってください。その後は市販の刃物油やさび止め油を塗って革ケースで保管してください。●切れ味が悪くなったり、刃が欠けたりしたら、砥石を軽く水で濡らし、荒い砥石で研いだ後、細かい砥石で仕上げます。

⚠ About the product

Due to the properties of the material each part is finished individually by hand. For this reason, some fine scratches may be left on the machete. We would ask for your understanding.



Cautions

Risk of injury or damage to equipment.

- Do not touch the blade directly with your hand.
- Do not swing around.
- Keep away from fire.
- Keep out of reach of children.
- Do not use for cutting metal.



- Do not use to cut materials with strong vertical fibers, such as bamboo, using a side swing as the machete may rebound and cause injury. Please use a saw instead.

⚠ Precautions for use

- It is very dangerous to swing the machete downward from a height higher than necessary or apply excessive force. The machete might twist and glance off the firewood.●Swinging the machete down with excess force will not only be tiring but also increase the risk of injury. Split firewood by using the weight of the machete only.●If left wet, the machete will damage quickly. Store in a dry room to prevent the blade from rusting.●Please keep out of reach of children.●Dropping the machete may cause damage.●Do not touch the blade with bare hands.●Do not overswing the machete.●Keep away from fire.●Do not use the machete for any other purpose.●Please check this product does not have a chipped blade, looseness, or cracks before using.●Wear work or leather gloves to protect your hands.●Please be sure to keep this manual with the machete, including if the product is given or lent to another person.

INSTRUCTIONS

- 【Splitting】When splitting firewood, please place a wooden stand under it to avoid accidentally hitting the blade on the ground and causing damage to the equipment or injury. If the wood does not break, use an auxiliary tool (such as a wooden mallet or other wooden object) to hit the back of the blade to break it.
- 【Cutting】It can be used for cutting branches.
- 【Sharpen】When felling a tree or shaving branches into thin pieces, cut the fiber of the trunk from a diagonal direction for ease of cutting. *Do not twist the machete while the edge of the blade is biting into the firewood. (There is a risk of chipping the blade.)

CARE AND STORAGE

- Please wipe off any water or dirt with a dry cloth after use.●Please clean with a moist cloth using water with dishwashing liquid if it is heavily soiled. After this, apply commercially available cutlery oil or rust preventive oil and store it in a leather case.●If the blade becomes dull or chipped, slightly wet the whetstone with water, sharpen it with a coarse whetstone, and then finish with a fine whetstone.

〈品質表示 Quality Indication〉

材質: 本体 刃物鋼(鉄) カバー: 革
幅: 約40mm(刃部分) 縦: 約270mm
厚さ: 約6mm 重量: 約337g

Main Body: Carbon steel Cover: leather
Width: approx.40mm Height: approx.270mm
Depth: approx.6mm Weight: approx.337g