

取扱説明書



PEG CONRO SOLO BOARD

ペグコンロソロボード

※ご使用前にこの説明書を必ずお読みください。

〈品質表示〉	本体材質：朴の木(ホオノキ) MADE IN JAPAN	幅：約257mm 奥行：約157mm	高さ：約15mm 重量：約268g
--------	---------------------------------	-----------------------	----------------------

安全上の注意

- ご使用の際は「使用上の注意」等をよくお読みください。
- 溝がついている面はペグコンロソロの熱からテーブルを守るボードとして、TSBBQロゴマークが入っている面はまな板として使えます。

⚠ ご使用上のご注意

- 長時間水に浸しておくとう木の老化を早め、変形や変色の原因となりますのでおやめください。
- 使用する前に平らな場所においてください。
- 濡らさないでまな板として使うと食材の水分を吸ってしまい臭いが移ってしまうので、必ず濡らしてからお使いください。
- 食器洗浄乾燥機には使用しないでください。

使用方法

- 使用時、水で表面を濡らして拭いてください。水分による膜ができ木に臭いが移りにくくなり表面が汚れにくくなります。
- ペグコンロソロの下に置く場合、溝部分にペグが入るようにセットしてください。
- まな板として使う場合、使用後はなるべく早く水やお湯でよく洗い水気を切って良く乾かしてから保管してください。
- 汚れは食器用洗剤などで洗い落してください。

お手入れ・保管について

- 急激な乾燥や直射日光による長時間の乾燥などはボードが割れる恐れがありますのでおやめください。
- 湿ったまま保管するとカビ・黒ずみの原因となりますので、乾燥させてから保管してください

村の鍛冶屋 株式会社山谷産業

〒955-0053 新潟県三条市北入蔵2丁目2-57

TEL.0256-38-5635 FAX.0256-38-6489 <https://www.yamac.co.jp/>

Instruction Manual



PEG GRILL SOLO BOARD

※Always read these instructions before use.

(Quality Indication)

Main Body : magnolia
MADE IN JAPAN

Width : approx.257mm Height : approx.15mm
Depth : approx.157mm Weight : approx.268g

Safety Precautions

- Please read these Safety Precautions when using the board.
- The side with the groove can be used as a board to protect the table from the heat of the Peg Grill Solo, while the side with the TSBBQ logo mark can be used as a chopping board.

⚠ Precautions during Use

- Do not leave soaking in water for any length of time since this will cause rapid deterioration of the wood and make it warp or change color.
- Place on a flat surface before use.
- If you use as a chopping board without dampening it first, the board will soak up moisture from the ingredients and smells will be transferred to the wood. Always dampen before use.
- Do not use in a dish washer or dryer.

Instructions for Use

- Dampen the surface with water and wipe. Water forms a film and this means that smells are not transferred to the wood and the surface does not get dirty.
- When placing underneath the peg grill solo, set so that the pegs are in the groove.
- When using as a chopping board, wash well with water or hot water immediately after use, let the moisture drain off and dry carefully before storing.
- Wash off dirt with dish detergent.

Care and Storage

- Avoid rapid drying or leaving to dry for any length of time in direct sunlight since this may cause the board to split.
- Store after drying. If the board is put away while still wet mold or black spots may form.