MURANOKAJIYA Dresen,

Try! Stylish BBQ!



使用可能熱源









取扱説明書

HOT SAND MAKER



ホットサンドの作り方

【材料】

- ●食パン … 2枚(6枚切りか8枚切りのものを使用)
- ●バター … 適量
- ●お好みの具材 (レタス・トマト・ハム・スライスチーズ・ポテトサラダなど)

【手順】

- ①食パン2枚の両面にバターを塗ります。 ホットサンドメーカーにパンを1枚のせ お好みの具材を重ねます。
- ※お好みでバターは塗る必要はありません。 その場合はホットサンドメーカーに薄くサラダ油を塗ってください。
- ②もう1枚のパンをのせて、 ホットサンドメーカーを閉じます。
- ③ホットサンドメーカーをストッパー金具で固定し、 パンの表面がきつね色になるまで 焼いたら出来上がりです。

中を確認しながらお好みの焼き加減で調節してください。 (目安:弱火~中火で片面約2~3分)


※取り出す際は非常に熱くなっていますので やけどしないよう十分にご注意ください。

※リベットについて -

リベットは鉄製のため錆びることがあります。食用油などをご使 用前に薄く塗ることで錆を防止することができます。万一、錆が 発生しても性能に差し支えはございません。










/ 着脱方法について

- ●着脱は図①のように上下のハンドルを両手でしっ かりと持って行ってください。
- ●図②のように約45度の角度に開くと着脱できます。 ※調理中に着脱部分が外れないよう十分にご 注意ください。
- ●着脱することで使用後洗いやすくなり、またミニフ ライパンの様に片面だけで使用する事もできます。
- ●少量のお弁当のおかず作りや、ホットケーキ・目玉 焼き・焼きおにぎり等、ホットサンド以外にもいろい ろなお料理に使って頂けます。





⚠ ご使用上のご注意

- ●ハンドルに破損やガタツキがないか安全を確認してからご使用ください。
- ●初めてのご使用の際は、食器用洗剤でよく洗ってからご使用ください。
- ●空炊きをしないでください。
- ●強い衝撃や急激な温度変化を与えないでください。製品の変形、破損の原因になります。
- ●調理の際はストッパー金具をしっかりはめてご使用ください。
- ●取っ手が勢くなることがあります。やけどの恐れがありますのでご注意ください。
- ●調理中・調理後は熱くなっていますので、本体に手を触れないでください。
- ●コンロの中央に載せ、安定した状態でご使用ください。
- ●料理を長時間保存しないでください。フッ素樹脂加工の劣化の原因となります。
- 製品にガタツキや破損が生じた場合は改造や応急処置をせず使用を中止してください。
- ※ガス機器にてご使用の場合は必ず換気扇を回すか、窓を開けてください。 換気をしないと、不完全燃焼による一酸化炭素中毒のおそれがあります。 詳しくはガス機器の取扱説明書をご覧ください。

〈品質表示〉(IH非対応)

本体:アルミニウム合金(フッ素樹脂膜加工) ハンドル:ステンレス/フェノール樹脂

重量:777g サイズ:16×37.4cm

MADE IN JAPAN

村の鍛冶屋 株式会社山谷産業

〒955-0053 新潟県三条市北入蔵2丁目2-57

TEL.0256-38-5635 FAX.0256-38-6489 http://www.yamac.co.jp/



Try! Stylish BBQ!



Suitable for use with the following heat sources





Halogen





Instruction Manual

HOT SANDWICH



How to make a Hot sandwich

(Ingredients)

- •2 slices of bread (use 6-slice or 8-slice loaf)
- pat of butter
- desired filling (lettuce, ham, slice of cheese, potato salad, etc.)

[Method]

- Spread butter on both slices of bread. Place one slice on hot sandwich maker and spread with filling.
- * You don't need to butter bread if you don't want to. If you don't use butter, put a little salad oil on hot sandwich maker instead.
- 2. Place other slice of bread on top and close hot sandwich maker.
- 3. Lock hot sandwich maker shut with metal catch on stopper. When bread has toasted to a light brown color, sandwich is ready. Check inside and adjust heat accordingly till bread has toasted to desired color. (Guide: 2-3 minutes per side at low or medium heat)
- *Sandwich maker will be very hot when you take sandwich out. Be careful not to burn yourself


* Rivet

Rivet is made of metal and may rust. You can prevent rust by wiping lightly with oil or fat before use. Even if rivet does rust, this has no effect on performance.





Open from time to time to check how bread is toasting.





Sandwich is ready when it has been turned over and both sides are toasted a nice brown color!






Attaching/Detaching =

- -This is done by holding upper and lower handles firmly with both hands as in Fig 1.
- -Plates can be attached/detached by holding them open at an angle of 45° as shown in Fig 2.
- *Make sure that hook holding plates together doesn't come out while making sandwich.
- -Since plates can be detached they are easy to wash. One plate can also be used on its own as a small frying pan.
- -Hot sandwich maker can be used for various other types of food in addition to sandwiches; small bento (lunch box) items, pancakes, fried egg, fried onigiri (rice ball), etc.







Precautions during use =

- Before using, make sure that handle is neither broken nor loose.
- Wash well with dishwashing detergent before using for first time.
- Do not use while empty.
- Do not subject to hard knocks or sudden temperature changes since this might cause warping or breakage.
- Close metal catch on stopper firmly during use.
- Handle may become hot. Be careful of burns.
- Since sandwich maker becomes hot during and after cooking, do not touch the main body.
- Place on center of burner and make sure it is stable during use.
- Do not keep food for any length of time since this will cause fluororesin processing to deteriorate.
- If product becomes shaky or breaks, stop using it. Do not attempt any do-it-yourself repairs.
- *If using on a gas appliance, be sure to switch on ventilation fan or open a window.
- If ventilation is poor, there is a danger of carbon monoxide poisoning due to incomplete combustion. Please read gas appliance instruction manual for more details.

Quality Display (unsuitable for microwaves)

Main Body: aluminum alloy (fluororesin processing) Handle: stainless steel/fluororesin

Weight: 777g Size: 16 × 37.4cm

Made in Japan

Muranokajiya Yamatani Industry Co., Ltd.

2-2-57 Kitanyugura, Sanjo City, Niigata Prefecture 955-0053, Japan

Tel: +81-256-38-5635 Fax: +81-256-38-6489 http://www.yamac.co.jp